


(PAIOR ART)

## QR-1 Spring Brake QR Valve 4X2 OR 6X2 STRAIGHT TRUCK W/ R-7/ RV-3/ QR-1 R-12 Service Relay Valve R-7 Spring Brake Modulation Valve PP-DC Control Valve E-6 Foot Control To and From Steer Axle .....



SR-6
Spring Brake Modulating / Relay Valve
Operation: System Charging < 105 psi






FIGURE 4


SR-6
Spring Brake Modulating / Relay Valve
Operation: System Charged > 105 psi




SR-6
Spring Brake Modulating / Relay Valve
Operation: Normal service application




SR-6
Spring Brake Modulating / Relay Valve
Operation: System Park



SR-6
Spring Brake Modulating / Relay Valve
Operation: Service application with primary failure



SR-6
Spring Brake Modulating / Relay Valve
Operation: Service application with secondary failure



SR-6
Spring Brake Modulating / Relay Valve
Operation: Anti-Compounding




FIG. 10

